



**NUOVO ARTICOLO - NEW ITEM**  
**2017**

<b>CODICE ARTICOLO</b>	<b>REFERENCE NO.</b>	10500111 - 10500112
<b>DESCRIZIONE</b>	<b>ITEM DESCRIPTION</b>	<b>PARAFANGO ANTERIORE DS/SN FRT WING (FNDR) RH / LH</b>
<b>SIMILE A</b>	<b>SIMILAR TO</b>	1890155 / 1839495
<b>MARCA</b>	<b>MANUFACTURER</b>	<b>FORD</b>
<b>MODELLO</b>	<b>CAR MODEL</b>	<b>CUSTOM 2013-&gt;</b>
<b>TIPO VETTURA</b>	<b>TYPE OF CAR</b>	
<b>1 PC = KG</b>		<b>2,80</b>
<b>1 M<sup>2</sup> = PCS</b>		<b>15</b>
<b>DATA</b>	<b>DATE</b>	<b>06 / 2017</b>

10500112

